





06 cleaning & washing

DWD0011




DWD0011




06 cleaning & washing

DWD0011



DWD0011






03_061_e

06 cleaning & washing

DWD0011



DWD0011




05_005_e

06 cleaning & washing


DWD0011



DWD0011




VERSIONE STANDARD / VERSIONE POMPA AUM. PRESSIONE
STANDARD VERSION / BOOSTER PUMP VERSION
VERSION STANDARD / VERSION POMPE AUGMENT. PRESSION




cleaning & washing

DWD0011




DWD0011




06 cleaning & washing

DWD0011



10_004ae


DWD0011




11_004_e

06 cleaning & washing

DWD0011




DWD0011




06 cleaning & washing

DWD0011




13_124ae

DWD0011




14_004_e




06 cleaning & washing

DWD0011




17_129_e

DWD0011



17_129be


DWD0011



VERSIONE ECONOMICA "ECO"
"ECONOMY VERSION "ECO"
VERSION ECONOMIQUE "ECO"

17_139_e

DWD0011



VERSIONE ECONOMICA "ECO"
"ECONOMY VERSION "ECO"
VERSION ECONOMIQUE "ECO"

17_139_e

STOCK CODE	DESCRIPTION	MAN.PART NUMBER	DRAWING REF
XDWD1000	DISHWASHER DIHR-SINGLE SOLENOID (HT11/11S)	DW30001000	800
XDWD2002	DISHWASHER DIHR-BOILER CASING (11S/HT11)	22002/75205/30002	1605
XDWD9982	DISHWASHER DIHR TUNNEL AX161 - WASH TANK ELEMENT	DW30001011/A	1610
XDWD0706	DISHWASHER DIHR-PRESSURE SWITCH (GS40/GS50)	DW10706/A	28505
XDWD2003	DISHWASHER DIHR-16A SWITCH (HT11) DEVIATOR	DW15812	42155
XDWD4040	DISHWASHER DIHR- PILOT LIGHT(HT11)	DW15826	42175
XDWD9993	DISHWASHER DIHR - LEFT/RIGHT SLIDE BEARING	DW11600055	42490
XDWD1160	DISHWASHER DIHR- RACK FRAME	DW11600001	42495
XDWD5116	DISHWASHER DIHR-FEET(HT11 AND 11S)	DW15116	42515
XDWD3625	DISHWASHER DIHR-DRAIN CONNECTOR (HT11/GS50)	DW500606	42520
XDWD0047	DISHWASHER DIHR-TANK ELEMENT 2.7KW-(ht 11-GS45)- FLAT	DW150047	42525
XDWD9958	DISHWASHER DIHR-BASKET SUPPORT HOLDER PIN	DW11600018	42535
XDWD4907	DISHWASHER DIHR- STRAINER PLATE(HT11 & AX161)	DW11600907	42540
XDWD0305	DISHWASHER DIHR-HOOD LIMIT SWITCH FOR HT11(back	DW70305	42555
XDWD9960	DISHWASHER DIHR- GUIDE RAIL	DW10600923	42565
XDWD4615	DISHWASHER DIHR- FERRULE FILTER(HT11/GS50)	DW500615	42570
XDWD0616	DISHWASHER DIHR-DRAIN FILTER - (HT11/GS45/50/40)	DW500616	42575
XDWD0619	DISHWASHER DIHR-OVERFLOW PIPE (HT11)	DW500619	42585
XDWD3530	DISHWASHER DIHR-WASHER (GS50)	DW80208	42590
XDWD9961	DISHWASHER DIHR-SLEEPER HOLDER FILTER	DW76007	42595
XDWD0700	DISHWASHER DIHR-DOOR SPRING (DERBY)	DW10700	42598
XDWD0306	DISHWASHER DIHR-SPRING HOOK JOINT (11S)	DW70306	42630
XDWD4030	DISHWASHER DIHR- BEARING HOLDER(HT11)	DW11600030	42660
XDWD0551	DISHWASHER DIHR-CONNECTION BLOCK 3PH	DW500551	42705
XDWD9983	DISHWASHER DIHR TUNNEL AX161 - THERMSTATS	DW2000430	42710
XDWD0707	DISHWASHER DIHR-THERMOSTAT (HT11/11S/GS40/50)	DW10707/1	42715
XDWD1508	DISHWASHER DIHR-CONTACTOR (15086/F) (HT11)	DW15086	42725
XDWD0118	DISHWASHER DIHR-LOW NOISE FILTER	DW15149	42750
XDWD9964	DISHWASHER DIHR-ELECTRONIC TIMER (HT11 2009)	DW50553/A	42755
XDWD2009	DISHWASHER DIHR-COMPLETE MOTOR (11S)	DW22009	42800
XDWD0612	DISHWASHER DIHR-UPPER/LOWER TURRET(GS50)	DW500612	42900
XDWD0321	DISHWASHER DIHR-NYLON BUSH	DW75321	42925
XDWD0317	DISHWASHER DIHR-NUT FOR IMPELLER HUB	DW75317	42930
XDWD7532	DISHWASHER DIHR-HUB FOR ROTOR (11S)	DW75320	42935
XDWD0915	DIHR D/WASHER *WASHARM*(STAINLESS STEEL 11S)	DW75915	42940
XDWD5918	DISHWASHER DIHR - RINSE ARM COMPLETE [HT11]	DW75920/D	42945
XDWD5322	DISHWASHER DIHR-EXT RINSE AXIS (11S)	DW75322	42990
XDWD5067	DISHWASHER DIHR-TOP GLASS WASH RINSE(11S	DW75067	42995
XDWD5319	DISHWASHER DIHR-RINSING ELBOW (11S)	DW75319	43000
XDWD2006	DISHWASHER DIHR-RINSE PIPE FITTING (11S)	DW12006/A	43035
XDWD0799	DISHWASHER DIHR-3 WAY DOSING DEVICE(11S)	DW10799/G	45225